



Insight – Acoustic Glass Moving Walls

Operation & Maintenance Manual

www.creatif.org.uk

02_Contents

Thank you for choosing Thank you for choosing Insight by Creatif – a glass wall that delivers both maximum transparency and optimal acoustic performance.

This guide is designed to walk you through how to use the Insight system.

For technical drawings, please contact Creatif.

Page 03 - 06

Page 07

Page 08

Operation Guide

Cleaning & Maintenance

Contact

Servicing

Do you have a problem with your moving wall system or do you want to ask a question?

Email: service@creatif.org.uk

Guarantees

All materials were supplied by, or on behalf of, Creatif and manufactured in our factory.

All materials are guaranteed for 12 months from the date of installation, with the exception of component failure caused as a result of misuse or neglect.

03_Operation Guide 1 of 4


This guide assumes that your system is closed (forming a wall). If your system is open (stacked), please complete this process in the reverse order.

Step 1



Start by electronically unlocking the wall panels. This is done via the control panel, which is located on the expanding jamb (see fig. A).

To activate the device, simultaneously press and hold both “Open” and “Close” until the buttons flash (see fig. B).


Then, press “Open” to unlock the first panel. This will be signalled by a beep.



Panel



Close-up




04_Operation Guide 2 of 4

Step 2



After the beep, you can stack away the panel. Using both hands, move the now unlocked panel a few centimetres away from the next fixed panel in the set, so you can see the other side (see fig. A).

Now rotate the panel 90 degrees, and proceed to place it into the desired stacking area or designated stacking area by moving it along the track (see fig. B).


While the panels are in motion, take care not to slam them into any surfaces.



Move the panel



Rotate & stack
(aerial view)



05_Operation Guide 3 of 4


Step 3

To stack the remaining panels, you will need to unlock each of them individually. Return to the control device and press “Open” to free-up the next available panel.

Then, complete Step 2 and continue in this manner until all panels have been stacked away.

When all panels have been stacked correctly, turn the power to the system off by using the switch provided.

Note: In some systems, the switch may be key-operated.




06_Operation Guide 4 of 4

Step 4

To close the partitions and form a wall, move the panels into their required position and make sure the external profiles and electrical contracts are all aligned correctly.

To complete the procedure, press “Close” on the control device which will lock all the panels in place.

Note: Take care not to press the telescopic seals on the edge of the panels during operation.



07_Cleaning & Maintenance


Insight requires little attention, though users should ensure that the track is kept free of dirt and foreign objects.

The glass panels can be cleaned with any suitable product available on the market, though the aluminium profile should be cleaned with a humid cloth.

Please note that due to the use of electrics within an Insight system, never use water or a wet cloth to clean any part of the system.

For more info on a service contract, system usage or to activate your warranty, give us a call or send an email:

service@creatif.org.uk



08_Contact

If you have any questions about your moving wall system, or would like to find out more about our servicing packages, please get in touch;

T: +44 (0) 113 270 1239

E: service@creatif.org.uk

www.creatif.org.uk



**Do you have
a question?**

Want to discuss
servicing options?

Get in touch!